



TEMPUR® Ardennes and Moulton Standard Divans, and Headboards

Installation & Assembly Instructions

Fitting Castors – Unpack the base (both halves where applicable), lay base upside down and take off attached bag containing castors, linking bars, bolts and headboard bolts. Place castor into the insert as shown...



Linking – Turn the bases over on to castors. Place both halves of the base next to each other and fit silver linking bar to the head (top) end. Fasten bolts tightly as shown...



Then repeat at foot (bottom) end of the base



Attaching Headboards – When fitting headboards pierce the fabric beneath the stickers which mark where the headboard bolt holes are. Check the bolts can thread correctly by screwing them into the hole.





Attaching Headboards - Things To Note:

Fitting a headboard is always easier with two people.

Some models may have wooden blocks or spacers in addition to the long headboard bolts. If they do, these go in between the divan base and the headboard. This is often found on adjustable base units where they provide clearance for the mattresses as they are raised and lowered on the mechanisms.

Headboards With UK Strut Fixings

1. Attach the wooden legs to the headboard using the screws provided.
2. Set the headboard bolts in the base to slightly wider than the struts so the wooden prongs can slide over the gap between the bolt head and the base.
3. Once the headboard is in position, tighten the headboard bolts to clamp the struts in place ensuring the headboard is secure.

Floor Standing Headboards With Bolt Slots

1. Remove the headboard bolt fixings from the head of the divan base.
2. Offer the headboard up to the headend of the bed base so the slots align with the bolt holes.
3. Once the headboard is in position, tighten the headboard bolts to clamp the headboard in place, ensuring it is secure.